

FIG. 1

FIG. 2

FLOWCHART OF NORMAL OPERATION OF AFC PORTION




FIG. 3

FLOWCHART OF OPERATION OF AFC STATE
MONITORING PORTION





FIG. 4

FLOWCHART OF OPERATION OF AFC PORTION
UPON STOPPING COMMUNICATION



5 / 8

FIG. 5 PRIOR ART




FIG. 6

FLOWCHART OF OPERATION OF CONVENTIONAL AFC PORTION




FIG. 7

KNOWN SYMBOL PATTERN TRANSMITTED FROM BASE STATION





FIG. 8



SYMBOL WHEN FREQUENCY
ERROR IS NOT PRESENT

FIG. 9

